

Speedfit Operating



The Speedfit Clamp is designed to cover a wide range of pipe or tubing jobs. The Speedfit Fit Clamps have an operating range of 1"-12" / 25.4 – 304.8mm. Thin wall tubing to tubing, tubing to tee, tubing to elbow or tubing to valve are no problem for the SpeedfitClamp.

Back off the thumbscrew off the SpeedfitFit Clamp until the threaded end of the thumbscrews are inside of the pipe rest and will not contact the tubing, when the clamp is closed. Turn the "T" handle at the top of the clamp counter clockwise until the clamp will slide over the end of pipe or over the top of the pipe. Turn the "T" handle clockwise until the pipe rest is snug against the surface of the tubing clamp will slide over the end of pipe or over the top of the pipe. Turn the Thumbscrews clockwise until they are snug against the surface of the tubing. Release the clamp from the tubing by turning the "T" handle counter clockwise. Slide the clamp over the end of the pipe to the desired position and tighten the "T" handle. Back two thumbscrews one full turn and place the fitting in the Clamp. Adjust the thumbscrews in or out until the desired Hi-Lo is achieved.

PART #	CAPACITY Inches/ MM	WEIGHT KGS
SFC12	1-2 1/2 / 25-64	2
SFC26	2-6 / 50-150	5
SFC512	5-12 / 127-300	9

PCES Limited
Unit 20
Wulfrun Trading Estate
Stafford Road
Wolverhampton
WV10 6HH
Tel: 01902 713402
E-mail: martin@pces.uk.com
www.pces.uk.com

Call us for all your Pipecutting and Clamping needs

